

**DX6i Program Settings/Values for Blade 400 3D RTF\***

\*NOTE - All DX6i settings are the same as "default" unless specified

<b>ADJUST LIST</b>					
<b>D\ R&amp;EXPO</b>					
AILE	1	80%	30%		
ELEV	1	80%	30%		
RUDD	0/1	100%	30%		
<b>TRAVEL ADJ</b>					
RUDD	<- 80%	-> 80%			
<b>GYRO</b>					
RATE	SW- GYRO				
0:	66.5%				
1:	64.0%				
<b>THRO CUR</b>					
NORMAL	POS L	POS 2	POS 3	POS 4	POS H
	0.0%	42.5%	60.0%	80.0%	100.0%
STUNT	POS L	POS 2	POS 3	POS 4	POS H
	100.0%	92.5%	85.0%	92.5%	100.0%
HOLD	POS H				
	- 0.0%				
<b>PITC CUR</b>					
NORM	POS L	POS 2	POS 3	POS 4	POS H
	35.0%	42.5%	50.0%	75.0%	100.0%
HOLD	POS L	POS 2	POS 3	POS 4	POS H
	35.0%	42.5%	50.0%	75.0%	100.0%
<b>SWASH MIX</b>					
AILE		- 75%			
ELEV		- 75%			
PITC		+ 70%			
<b>SETUP LIST</b>					
<b>MODEL NAME</b>					
MODEL 1					
BLADE400					
<b>REVERSE</b>					
AILE - R					
RUDD - R					
<b>SWASH TYPE</b>					
CCPM 120*					
<b>TIMER</b>					
DOWN TIMER - 04:30					